

# WHAT'S IN THE BOX


Please read each step before you attempt to set up. Save these instructions for future reference. Return the Warranty Card within 10 days of purchase.

- 1 10' x 10' Express™ Frame Fully Assembled
- 1 Express™ Top
- 1 Carry Bag
- 4 Piece Stake Set


# HOW TO SET UP

## \*Note: First Time Attachment Is Required.

Top and frame are shipped unattached to avoid damage. A first time set up requires that top be bolted on to the frame. This first time set up takes longer than 60 seconds. Once top is permanently attached to frame, set up and take down are easily accomplished within seconds.




**1.** Place your E-Z UP® frame in the center of area to be sheltered. With partner on opposite side, grasp two outer legs, slightly lift off ground and step backwards, stopping at full arms' length - approximately 3/4 it's total size.




**2.** Gently unfold the fabric top and place it over the open frame.



**3.** Attach the top to the E-Z UP® frame by matching the loop fastening strip on the top with the hook fastening strip on the frame. Pull the corners down fully. Push the hook and loop firmly together at each corner.




**4.** To secure the top to frame, line up grommet holes on valance with the bolts on frame.




**5a.** With wrenches provided, remove the nut from each bolt (one at a time) and pull bolt out completely while holding the trusses, black washer spacer and angle bracket in place. Place top grommet hole in-line with the parts that you are holding and slide bolt through all parts.




**5b.** Put nut back on bolt on the inside of the trusses. Tighten nut so it is snug and the grommet can still rotate without a great deal of free play.



**6.** Grasp the bottom of the diamond shaped area of trusses on opposite sides. Lift up and step backwards until shelter is fully opened, being careful not to pinch fingers.




**7.** Engage the auto slider at each corner by pushing up with one hand while holding down the top of the leg with the other hand. The snap button will engage the hole. Then pull down the hem of the top. Repeat at all four corners.



**8.** Lift up two adjacent outer legs and slide out the inner legs until the snap button locks. Repeat on the opposite legs - make sure to do two legs at a time.

**Note:** Once top is permanently attached, only perform steps 1, and 6 - 8 to set up.


# HOW TO TAKE DOWN



**1.** Slightly lift up two adjacent outer legs, depress the snap button, and telescope the inner legs up into the outer legs. Repeat on the opposite legs - making sure to do two legs at a time.



**2.** Release the auto slider at each corner by reaching up under the hem and pushing the framework up slightly with one hand, while using other hand to depress and release the snap button. Repeat on all four corners.



**3.** Grasp the top diamond on opposite sides by "close" sticker. Lift the shelter up slightly and shake it while stepping towards your partner until the unit is 3/4 closed. With each partner grasping two outer legs, push frame together to fully close it - Be careful not to pinch fingers. Store frame in carry bag.

# IMPORTANT INFORMATION

**IMPORTANT!** Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

- Use caution when handling the E-Z UP® folding frame. Avoid pinching hands or fingers as frame opens or closes.
- Always stake or weight down your E-Z UP®. Do not use in any potentially windy or rainy weather. Wind and rain can damage the E-Z UP® Instant Shelter® and may also result in injury to you or others. Therefore, do not rely on shelter for protection in heavy or prolonged rain storms.
- Do not use shelter in a lightning storm.
- The E-Z UP® Instant Shelter® is designed as a temporary shelter. Do not leave up for extended periods.
- Do not leave your E-Z UP® Instant Shelter® unattended.
- Keep all flame and heat sources away from fabric top. Do not build fires within shelter enclosure.

Fire retardant - meets CPAI-84 requirements.

# CARE AND MAINTENANCE

For long lasting durability and the best possible protection for your E-Z UP® Express™, follow these E-Z care and maintenance instructions:

- Use a mild soap (not detergent) and plenty of water for top cleaning.
- Let the E-Z UP® top and frame dry completely before closing or storing to avoid mildew.
- Frame will operate and look better if occasionally wiped with silicone spray, especially before and after use in damp conditions. Remove excess silicone residue before applying top.
- Use a seam sealer if top leaks or drips water. Available at most sporting goods and hardware stores.
- Slightly tighten bolts if frame becomes loose.

Customer Service Hot Line  
(800) 235-5637